MAINTENANCE PLANNING GU	IDELINES 2006
or bar application of bituminous material and	stance.
 RECOMMENDED EQUIPMENT: Truck Distributor Chip Spreader Optional Brooms Rubber Tire Roller Trucks Optional Pilot Truck Traffic Control Equipment; reference the Traffic Control for Field Operations Manual RECOMMENDED MATERIAL: Liquid Binder – Sealing Grades Check with Materials Office for proper selection of aggregate. (³/₁₆-in. or less) Aggregate Size. Sand – Other Blot Material 	 RECOMMENDED PROCEDURE: Place traffic control devices as needed. Sweep the existing surface to clean and remove loose debris. Set temporary pavement marking. Apply asphalt at recommended rate and broom as necessary. Cover asphalt with blotting material. Broom blotting material. Remove traffic control devices, except "Fresh Oil" and "No Center Stripe" signs, and open to traffic. "Fresh Oil" and "Loose Gravel" signs should remain in place until surface is cured and loose aggregate has been thoroughly swept off.
Handbook) OTHER CONSIDERATIONS: Clean up exc	to Safety Policies, Rules & Regulations-Employee cess material with power broom. ations for Highway Construction; Section 413.20,

<u>R31C Chip Seals – Fine Aggregate</u>



(1) Cinder Seal Operation



(2) Dump Truck unloading Cinders into Chipper



(3) Dump Truck unloading Cinders into Chipper



(4) Chipper applying Cinders to Road Bed



(5) Rubber Tired Roller



(6) Cinder Seal Operation