



**TYPE 2 OBJECT MARKERS:**  
ERECT ONE AT BEGINNING AND END OF THE TAPER. SPACE OTHERS 2 FEET LATERALLY. MARKERS SHOULD BE 3 FEET OFF PAVEMENT EDGE OR AT THE SHOULDER POINT FOR STABILIZED SHOULDERS.

SEE CHAPTER 15 FOR USE OF TYPE 2 OBJECT MARKERS ON CLIMBING LANES.

SLOWER  
TRAFFIC  
KEEP  
RIGHT