616.8.21 (TA-21) Lane Closure on Near Side of Intersection - MT

	SIGN SPAC		TAPER LE Shoulder ⁷ (T1)	ENGTH (ft.) Lane ² (T2)	OPTIONAL BUFFER LENGTH (ft.) (B)	CHANNELIZ	ER SPACING (ft.) Buffer/ Work Areas
SPEED	Undivided (S)	Divided (S)				Tapers	
-35	200	200	-	245	250	15	25
)-45	350	500	-	540	360	20	50
)-55	500	1000	-	660	495	50	100
0-70	SA – 1000, S and SC -		-	840	730	60	100
Shoulder t	aper length based o		dshoulderwidth)o	offset 2 Lane	taper length based on 1	2 ft. (standard lane	width) offset
ADWAY 1	YPE SIG	N MAXI	MUM				Channelizer
	HEIG	HT WORK					Sign
	1' Porta	able					Truck or Trailer
RBAN	7' Post 1' Porta						Mounted Arrow Panel
URAL DIVI	7' Post	2 N	1i.				Protective Vehicle
JRAL UND	IVIDED 1' Porta 5' Post	able 3 N	1i.				Truck Mounted
s typical	application is app	nlicable to int	ersections				Attenuator (TMA)
	way control on a						Work Space
-	vehicle shall be						
ile work i	is in progress. Th	ne					
	ehicle should be						
	and flashing arro		-				4
ance of t	he work space, if	possible.					•
	ve vehicle may b						
	f the roadway is p elow, the work ve		-				
	n advance of the						
ace, and th	ne work vehicle v	vith a					
	ow panel and uses ts or strobe lights						
ating ngn	is of shobe lights						
	rd warning signa						
	instead of the veh ts or strobe lights						
ting ngn	is of shote lights	•					
	all direct traffic i						Protective Vehicle Roll-Ahead Space
	not both. The di shall match the d] 📔 🛛 📥	
1			1		●		(
	al application, a lo						
	ovements will no reverse setup sho					* ★_	
	ft-turn movemen					⊢ ↓ ^B	
ha work -	nace extends are	one the area	vally the			Τ	2
	pace extends acro ould be closed u				100	<u>+</u>	S 🔶 🍐
devices	shown in EPG 6	16.8.29 (TA-2	29)	(3	channelizers min.)		or V
osswalk (Closures and Pee	destrian Dete	ours.		(optional)	↓ ∢	SA CENTER LANE
short du	ration operations,	signs and ch	annelizers			l ↑ s	or SB
	ced or eliminated					↓ ○	
m = 1-11	monotion - 1		n faat1				S A
	operations where ne operation, char			↓ ↓	1 1		or
	liminated.					⊥ ∢	SC ROAD WORK
		1	1.4.11			1	AHEAD
	ble, signs should ed approach.	be posted on	both sides				
arreett	a approach.						(Advanced Wai Rail System)
	ed facilities, char		ng may be				For Long Term Ope
iced to $\frac{1}{2}$	² spacing noted ir	n table.					· · · · ·
malamant	tal warning metho	de may be u	sed to call				

TA-21

Supplemental warning methods **may** be used to call attention to the work zone.

For long-term operations, refer to EPG 616.6.2.2 Flags and Advance Warning Rail System.